

# SURFACE WATER FLOODING

Also known as pluvial flooding, it occurs when the volume of rainfall exceeds the capacity of drains and surface water sewers and is unable to drain away through drainage systems or soak into the land, and instead flows over the land.



The intensity of this flooding can be increased by blocked road gullies, drains and sewers.